



Revision: 1.1 - 02/19/2010

INCLUDED IN THE KIT:

(2) - M6 Set Screws (installed)	(4) - M8x20 Cap Head Screws
(4) - M5 Set Screws (installed)	(2) - Longboard Mounts

INSTRUCTIONS:

NOTE: We recommend the use of blue Loctite on all fasteners/mounting hardware.

- Unhook spring from underside of stock floorboard.
- Remove E-clips from stock pivot pins and remove pins. Retain pin and E-clip as they will be reused. The spring will not be reused.
- Install new floorboard mounts to frame where stock boards were removed, using hardware removed in previous step.
- Attach new Longboards onto mounting brackets in desired position using supplied M8 cap-head screws. NOTE: not all positions may be usable in all applications.
- After mounting screws are tightened, tighten set screw on each end of mount bracket to hold mounting screws in place.
- Adjust heel shifter so it does not touch floorboard during downshifts. NOTE: heel shifters are removable on most models.
- Use set screw on bottom of mount brackets to set desired angle to boards.

Our install guides provide a basic outline on the proper installation of our products. Further tuning and/or fitment may be required. Barons bears no responsibility on installation costs associated with this product.
© 2013 Barons Custom Accessories